



ENSURE THE POSITION OF THE HOLES
MATCHES THE POSITION OF HOOKS BEFORE DRILLING
INTO YOUR WALL.

ferm
LIVING

Attention note:

Make sure to use the right type of screw and plug applicable to your wall.
The screws included are not suitable for gypsum and thin walls.

